

\*WHERE AIR RELEASE/VACUUM VALVE CANNOT BE TIED BACK INTO A WASTEWATER MANHOLE USE OPTION 2.

LIMITS OF PAY FOR THIS ITEM INCLUDES THE FOLLOWING:

1. INSTALLING THE TAPPING SADDLE AND CORP. STOP ONTO THE MAIN.
2. INSTALLING THE 2" PVC SCH. 80 FROM MAIN TO MANHOLE LOCATION.
3. INSTALLING THE MANHOLE (SEE STANDARD MANHOLE DETAIL).
4. INSTALLING THE AIR/VAC VALVE.


SCALE: NOT TO SCALE



MARBLE FALLS  
800 THIRD STREET  
MARBLE FALLS, TX 78654  
PH: (830) 693-6737

These documents were prepared by,  
or under the supervision of:

ERIC BELAJ 107148 May 31, 2017  
Engineer's Name PE# Date

  
Engineer's Signature

SECTION  
**WASTEWATER**

DETAIL NO.  
**WW-22**

TITLE  
AIR RELEASE  
VACUUM VALVE